



PLEASE READ

This user manual is from the manufacturer — **Jive Communications may not support some features discussed in this document.**

Please see our online documentation or contact us for a complete list of supported features.

Thanks for choosing Jive!



W53P & W60P DECT IP Phone User Guide

Version 83.10
Aug. 2018

Copyright

Copyright © 2018 YEALINK(XIAMEN) NETWORK TECHNOLOGY

Copyright © 2018 Yealink (Xiamen) Network Technology CO., LTD. All rights reserved. No parts of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, photocopying, recording, or otherwise, for any purpose, without the express written permission of Yealink (Xiamen) Network Technology CO., LTD. Under the law, reproducing includes translating into another language or format.

When this publication is made available on media, Yealink (Xiamen) Network Technology CO., LTD. gives its consent to downloading and printing copies of the content provided in this file only for private use but not for redistribution. No parts of this publication may be subject to alteration, modification or commercial use. Yealink (Xiamen) Network Technology CO., LTD. will not be liable for any damages arising from use of an illegally modified or altered publication.

Trademarks

Yealink®, the logo and the name and marks is trademark of Yealink (Xiamen) Network Technology CO., LTD, which are registered legally in China, the United States, EU (European Union) and other countries.

All other trademarks belong to their respective owners. Without Yealink's express written permission, recipient shall not reproduce or transmit any portion hereof in any form or by any means, with any purpose other than personal use.

Warranty

(1) Warranty

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS GUIDE ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS GUIDE ARE BELIEVED TO BE ACCURATE AND PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF PRODUCTS.

(2) Disclaimer

YEALINK (XIAMEN) NETWORK TECHNOLOGY CO., LTD. MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS GUIDE, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Yealink (Xiamen) Network Technology CO., LTD. shall not be liable for errors contained herein nor for incidental or consequential damages in connection with the furnishing, performance, or use of this guide.

(3) Limitation of Liability

Yealink and/or its respective suppliers are not responsible for the suitability of the information contained in this document for any reason. The information is provided "as is", and Yealink does not provide any warranty and is subject to change without notice. All risks other than risks caused by use of the information are borne by the recipient. In no event, even if Yealink has been suggested the occurrence of damages that are direct, consequential, incidental, special, punitive or whatsoever (Including but not limited to loss of business profit, business interruption or loss of business information), shall not be liable for these damages.

Declaration of Conformity

Hereby, Yealink(Xiamen) Network Technology CO., LTD. declares that this phone is in conformity with the essential requirements and other relevant provisions of the CE, FCC.

For European, this device is a DECT Portable station operating in the frequency band of 1880MHz to 1900MHz.

For US, This telephone is compliant with the DECT 6.0 standard which operates in the 1.92GHz to 1.93GHz frequency range.

CE Mark Warning

This device is marked with the CE mark in compliance with RED 2014/53/EU.

This device complies with the following standards:

1. Safety: EN 60950-1:2006+A11:2009+A1:2010+A12:2011+A2:2013
2. SAR: ETSI EN 62311:2008
3. EMC: EN55032:2012/AC:2013, EN55024:2010, EN301489-6 V2.1.1, EN301489-1 V2.1.1
4. Radio: ETSI EN 301406 V2.2.2

Industry Canada (IC)

This Class [B] digital apparatus complies with Canadian ICES-003 & ICRSS-213 Rules.

Operation is subject to the following conditions:

1. This device may not cause interference.
 2. This device must accept any interference, including interference that may cause undesired operation of the device.
- Privacy of communications may not be ensured when using this telephone.

Information for DECT Product



This telephone is compliant with the DECT 6.0 standard which operates in the 1.92GHz to 1.93GHz frequency range. Installation of this equipment is subject to notification and coordination with UTAM. Any relocation of this equipment must be coordinated through and approved by UTAM. UTAM may be contacted at 1-800-429-8826.

End User License Agreement

This End User License Agreement ("EULA") is a legal agreement between you and Yealink. By installing, copying or otherwise using the Products, you: (1) agree to be bounded by the terms of this EULA, (2) you are the owner or an authorized user of the device, and (3) you represent and warrant that you have the right, authority and capacity to enter into this agreement and to abide by all its terms and conditions, just as if you had signed it. The EULA for this product is available on the Yealink Support page for the product.

Patent Information

China, the United States, EU (European Union) and other countries are protecting one or more patents of accompanying products and/or patents being applied by Yealink.

Customer Feedback

We are striving to improve our documentation quality and we appreciate your feedback. Email your opinions and comments to DocsFeedback@yealink.com.

Technical Support

Visit Yealink WIKI (<http://support.yealink.com/>) for the latest firmware, guides, FAQ, Product documents, and more. For better service, we sincerely recommend you to use Yealink Ticketing system (<https://ticket.yealink.com>) to submit all your technical issues.

GNU GPL INFORMATION

Yealink W53P/W60P DECT IP phones firmware contain third-party software under the GNU General Public License (GPL). Yealink uses software under the specific terms of the GPL. Please refer to the GPL for the exact terms and conditions of the license.

The original GPL license, source code of components licensed under GPL and used in Yealink products can be downloaded online: http://www.yealink.com/onepage_83.html.

Table of Contents

Table of Contents	6
About This Guide	11
Related Documentation	11
In This Guide	11
Getting Started with Your Phone	13
Hardware Overview	13
W60B Base Station Hardware	13
W56H Handset Hardware	14
W53H Handset Hardware	15
Power LED Indicator on the Handset	16
Menu	16
Main Menu	17
Entering the Main Menu	18
Accessing the Main Menu Feature	18
Submenu	18
Accessing a Submenu Feature	19
Returning to Idle Screen	19
Screen and Icons	19
Idle Screen	19
Line Status Screen	20
Icons on the Idle Screen	20
Icons on the Calls Screen	21
Icons on the Line Status Screen	21
Call History Icons	21
Entering Characters on the Handset	22
Setting the Input Modes	22
Editing Fields	22
Entering Data	22
Customizing Your Phone	25
Turning Handset On	25
Turning Handset Off	25
Changing the Base PIN	25
Changing the Wallpaper	26
Setting the Screen Saver	26
Changing the Screen Brightness	26
Setting the Keypad Light	26
Changing the Language	27
Time & Date	27
Setting the Time and Date Manually	27
Changing the Time and Date Format	27
Shortcuts	28

Supported Shortcuts	28
Customizing the Shortcuts	29
Handset Keypad Lock	29
Locking Handset Keypad	30
Unlocking Your Phone	30
Handset Registration	30
Registering a Handset to a Base Station	30
Registering a Handset to Multiple Base Stations	30
Deregistering a Handset	31
Selecting a Base Station to Connect	31
Renaming the Base Station	31
Silent Mode	32
Switching on Silent Mode	32
Switching off Silent Mode	32
Locating a Handset	32
Renaming the Handset	32
Eco Mode+	33
Setting the Eco Mode+	33
Eco Mode	33
Setting the Eco Mode	33
Repeater Mode	33
Setting the Repeater Mode	34
Audio Settings	35
Adjusting the Volume	35
Adjusting the Audio Volume	35
Adjusting the Ringer Volume	35
Setting the Ring Tone	35
Setting the Ring Tone for the Internal Calls	36
Setting the Ring Tone for the External Calls	36
Setting the Advisory Tone	36
Directory	37
Local Directory	37
Adding Contacts	37
Editing Contacts	37
Deleting Contacts	37
Deleting a Contact	38
Deleting All Contacts	38
Searching for Contacts	38
Shared Directory	38
Adding Shared Contacts	38
Editing Shared Contacts	39
Deleting a Shared Contact	39
Deleting All Shared Contacts	39
Searching for Shared Directory Contacts	39

Moving a Shared Contact to the Local Directory	40
Placing a Call from the Shared Directory	40
Blacklist	40
Adding a Blacklist Contact	40
Editing a Blacklist Contact	40
Deleting Blacklist Contacts	41
Deleting a Blacklist Contact	41
Deleting all Blacklist Contacts	41
Remote Phone Book	41
Searching for Remote Phone Book Contacts	41
Adding a Remote Phone Book Contact to the Local Directory	42
Call History	43
Viewing History Records	43
Adding a History Record to Local Directory	43
Adding a History Record to Blacklist	43
Deleting History Records	44
Deleting a Call Record	44
Deleting All Call Records	44
Call Features	45
Switching Among the Receiver, Handsfree and Headset Modes	45
Changing the Default Outgoing Line	45
Placing Calls	45
Placing Internal Calls	46
Setting Auto Intercom	46
Placing an Internal Call	46
Placing an Internal Call During an External Call	46
Placing External Calls	47
Placing an External Call	47
Placing Multiple External Calls	47
Placing a Call from the Call History	47
Placing a Call from the Directory	47
Placing a Call with a Speed Dial Key	48
Assigning a Speed Dial Number	48
Changing a Speed Dial Number	48
Deleting a Speed Dial Number	49
Calling a Contact Using a Speed Dial Key	49
Redialing a Number	49
Redialing a Previously Dialed Number	49
Redialing the Last Dialed Number	49
Adding a Dialed Number to Local Directory	49
Deleting a Redial Record	50
Deleting All Redial Records	50
Placing an Anonymous Call	50
Enabling Anonymous Call	50

Placing an Anonymous Call	50
Answering Calls	51
Assigning Incoming Lines to the Handset	51
Answering a Call	51
Answering a Call When in a Call	52
Enabling Call Waiting	52
Answering a Call Automatically	52
Silencing or Rejecting Incoming Calls	52
Silencing a Call	52
Rejecting a Call Manually	53
Rejecting Anonymous Calls Automatically	53
Ending Calls	53
Muting/Unmuting Audio	53
Call Hold	53
Holding a Call	54
Resuming a Held Call	54
Swapping Between Active and Held Calls	54
Do Not Disturb (DND)	54
Rejecting Calls with DND	54
Call Forward	55
Forwarding Incoming Calls	55
Transferring Calls	55
Performing a Blind Transfer	56
Performing a Semi-Attended/Attended Transfer	56
Conference Calls	56
Local Conference	56
Setting Up a Local Conference Call	56
Joining Two Calls in a Conference	57
Muting or Unmuting a Conference Call	57
Ending a Conference Call	57
Network Conference	57
Setting Up a Network Conference	57
Inviting another Party into an Active Conference Call	58
Holding/Resuming a Conference Call	58
Ending a Conference Call	58
Multicast Paging	58
Sending Multicast Paging	59
Receiving Multicast Paging	59
Managing a Paging Call	59
Advanced Features	61
Call Park and Call Retrieve	61
Parking or Retrieving a Call in the FAC Mode	61
Parking a Call	61
Retrieving a Parked Call in the FAC Mode	62

Parking or Retrieving a Call in the Transfer Mode	62
Parking a Call in the Transfer Mode	62
Retrieving a Parked Call in the Transfer Mode	62
Retrieving a Call with a Retrieve Key	63
Setting a Retrieve Key	63
Retrieving a Parked Call using a Retrieve Key	63
Shared Line	63
State Indicator of Shared Line	64
Placing Calls on a Shared Line	64
Answering Calls on a Shared Line	64
Placing a Call on Public Hold	65
Placing a Call on Private Hold	65
Retrieving a Held Call Remotely on a Shared line	65
Barging In an Active Call on a Shared line	65
Pulling a Shared Call on a Shared line	65
Voice Mail	66
Setting the Voice Mail Code	66
Setting a Voice Mail Key for a Specific Line	66
Leaving Voice Mails	66
Listening to Voice Mails	66
Maintaining Your Phone	69
Investigating Warnings	69
Restarting the Base Station	69
Resetting the Base Station	69
Resetting the Handset	70
Triggering the Auto Provisioning	70
Appendix	71
Appendix A- Menu Structure	71
Appendix B - Input Modes and Characters	72

About This Guide

Yealink W53P/W60P DECT IP phone is a full-featured mobile device, which provides reliable and convenient wireless voice communications. In addition, it offers many widely accepted benefits of the DECT standard, including high security, strong scalability, and low power consumption to better meet your requirements.

This guide provides everything you need to quickly use your new phone. Firstly, verify with your system administrator that the IP network is ready for phone configuration. Also be sure to read the Quick Start Guide which can be found in your phone package before you set up and use the IP phone. As you read this guide, keep in mind that some features are only configurable by your system administrator or determined by your phone environment. As a result, some features may not be enabled or may be operated differently on your phone. Additionally, the examples and graphics in this guide may not directly reflect what is displayed or is available on your phone screen.

Note

This guide mainly takes W56H as an example. Due to different LCD specifications and parameters, the graphics displayed on the W53H handset may be different.

Read the [Yealink Products Regulatory Notices guide](#) for all regulatory and safety guidance.

Related Documentation

You can obtain additional information of the following phones from Yealink Support:

- [DECT IP Phone W60P](#)
- [DECT IP Phone W53P](#)

The following types of related documents are available on each support page:

- Release Notes, which details bug fixes and feature enhancements when an update is released.
- Quick Start Guide, which describes how to assemble your phone and configure the basic phone features.
- Administrator Guide, which provides the detailed information on how to configure phone features for system administrator.
- Regulatory Notice, which provides information about all regulatory and safety guidance.

In This Guide

Chapters in this guide include:

- Chapter 1 [About This Guide](#)
- Chapter 2 [Getting Started with Your Phone](#)
- Chapter 3 [Customizing Your Phone](#)
- Chapter 4 [Audio Settings](#)
- Chapter 5 [Directory](#)
- Chapter 6 [Call History](#)
- Chapter 7 [Call Features](#)
- Chapter 8 [Advanced Features](#)
- Chapter 9 [Maintaining Your Phone](#)
- Chapter 10 [Appendix](#)

Getting Started with Your Phone

This chapter provides the overview of phone hardware and screen layout, and introduces how to navigate your phone for the best performance.

Topics

[Hardware Overview](#)

[Menu](#)

[Screen and Icons](#)

[Entering Characters on the Handset](#)

Hardware Overview

Topics

[W60B Base Station Hardware](#)


[W56H Handset Hardware](#)

[W53H Handset Hardware](#)

[Power LED Indicator on the Handset](#)

W60B Base Station Hardware


After the base station starts up successfully and the handset is registered to the base station, all LEDs on the base station glow green in sequence.



	Item	Description
1	Paging Key	- Locates a misplaced handset. - Toggles the registration mode. - Resets the base station to factory settings.
2	Registration LED	Indicates handset registration status or the base station is in the paging mode.
3	Network Status LED	Indicates the network status.

	Item	Description
4	Power LED indicator	Indicates the power status of the base station.


W56H Handset Hardware



	Item	Description
1	Receiver	Receives audio in receiver mode.
2	Power LED indicator	Indicates call status, message status and charging status.
3	Phone Screen	Shows information.
4	Soft Keys	Access the function directly. It depends on the operating situation.
5	Message Key	Accesses the voice mail or missed call.
6	Speakerphone Key	- Switches among the receiver, headset and handsfree modes. - Answers an incoming call. - Places a call in handsfree mode.
7	Navigation Keys	Scroll through information or options on the screen.
8	OK Key	Confirms actions or enters the main menu.
9	On-hook Key/Power Key	- Press briefly to return to the previous screen. - Long press to return to the idle screen. - Press to turn the handset on.

	Item	Description
		• Long press on the idle screen to turn the handset off. • Cancels actions or ends a call. • Rejects an incoming call.
10	Off-hook Key	• Answers an incoming call. • Enters the redial calls list. • Places a call in receiver or headset mode.
11	Keypad	Provides digits, letters and special characters.
12	TRAN Key	Transfers a call to another party.
13	Mute Key	Toggles mute feature on or off.
14	Microphone	Picks up audio.
15	Speaker	Outputs audio in handsfree mode.
16	3.5mm Headset Jack	Connects a standard 3.5mm headset.

W53H Handset Hardware



	Item	Description
1	Receiver	Receives audio in receiver mode.

	Item	Description
2	Power LED indicator	Indicates call status, message status and charging status.
3	Phone Screen	Shows information.
4	Soft Keys	Access the function directly. It depends on the operating situation.
5	Message Key	Accesses the voice mail or missed call.
6	Speakerphone Key	• Switches among the receiver, headset and handsfree modes. • Answers an incoming call. • Places a call in handsfree mode.
7	Navigation Keys	Scroll through information or options on the screen.
8	OK Key	Confirms actions or enters the main menu.
9	On-hook Key/Power Key	• Press briefly to return to the previous screen. • Long press to return to the idle screen. • Press to turn the handset on. • Long press on the idle screen to turn the handset off. • Cancels actions or ends a call. • Rejects an incoming call.
10	Off-hook Key	• Answers an incoming call. • Enters the redial calls list. • Places a call in receiver or headset mode.
11	Keypad	Provides digits, letters and special characters.
12	TRAN Key	Transfers a call to another party.
13	Mute Key	Toggles mute feature on or off.
14	Microphone	Picks up audio.
15	Speaker	Outputs audio in handsfree mode.
16	3.5mm Headset Jack	Connects a standard 3.5mm headset.

Power LED Indicator on the Handset

LED Status	Description
Solid red	The handset is charging.
Fast flashing red (300ms)	The handset is ringing.
Slow flashing red (1s)	The handset receives a voice mail or has a missed call.
Off	The handset is powered off. The handset is idle. The handset is fully charged.

Menu

The handset provides a variety of features that are grouped into the menu.

Topics


[Main Menu](#)

[Submenu](#)

[Returning to Idle Screen](#)

Main Menu

The main menu is the top menu, which consists of seven menu items: Status, Intercom, Voice Mail, Call Features, Directory, Settings and History.



No.	Description
1	Menu item you selected.
2	Menu icon: : Status—To view the status information of base, handset and line. : Intercom—To make an internal call. : Voice Mail—To set and view voice mail(s). : Call Features—To access the features of Call Forward, Do Not Disturb, Call Waiting, Anon.Call Rejection, Anonymous Call and Paging. : Directory—To access the directory and manage the contacts. : Settings—To personalize the setting of your handset. : History—To access the call history list. Note: If your system administrator has enabled 3-level access permissions for you, you can see a User Mode icon .
3	Soft key label.

Topics

[Entering the Main Menu](#)

Accessing the Main Menu Feature

Entering the Main Menu

Procedure

1. Press the OK key when the handset is idle.
The main menus are displayed on screen as icons.

Accessing the Main Menu Feature

Procedure

1. Press **OK** when the handset is idle.
2. Press the navigation keys to select a different menu icon.
The name of the associated menu appears on the top of the screen.
3. Press **OK** to open the selected menu.

Note

You can only access **Status** and **Settings** if the handset is not registered to a base station. For more information on handset registration, refer to [Handset Registration](#).


Related Topic

[Appendix A- Menu Structure](#)

Submenu

The functions in the submenus are displayed as lists. You can open the submenu to access a function.

For example, if you select **Settings** menu, the submenu is displayed as below:



Topic

[Accessing a Submenu Feature](#)

Accessing a Submenu Feature

Procedure

1. Press the up and down navigation keys to highlight the desired submenu.
2. Press **OK** to open the submenu.
3. Press the On-hook key or **Back** to return to the previous screen.

Related Topic

[Appendix A- Menu Structure](#)

Returning to Idle Screen

Procedure

1. Long press the On-hook key to quickly exit the menu and return to the idle screen.

Screen and Icons

Before you use the phone, you need to be familiar with the state of your phone, including phone screen layout and icons.

Topics

[Idle Screen](#)

[Line Status Screen](#)


[Icons on the Idle Screen](#)

[Icons on the Calls Screen](#)

[Icons on the Line Status Screen](#)

[Call History Icons](#)

Idle Screen



• Signal Strength:

Weak to strong: 

No reception: 

Eco mode+ is on: 

- **Battery Status:**

Low to full: 

Need Charging: 

- **Status Bar:** Display the feature status icons. The status icons display when features are activated.
- **Handset Name:** Display internal handset number and registered handset name (e.g., "1" is internal handset number, indicating the handset is the Handset 1 of the base station).
- **Soft Keys:** The soft key labels on the screen directly above the soft keys show the functions available at that particular moment.


Related Topics

[Icons on the Idle Screen](#)

[Shortcuts](#)

Line Status Screen

Press **Line** to enter the line status screen. The line status screen is displayed as below:



- **Outgoing Line:** Display the registered line number and the corresponding line (display user name by default). The default outgoing line will be displayed in the first line of the screen.
- **Line Status:** Display the icon of line status. The icon indicates the corresponding feature that assigned to the line.

Related Topic

[Icons on the Line Status Screen](#)

Icons on the Idle Screen

Icon	Description
	Registered handset icon (e.g., "1" is internal handset number, indicating the handset is the Handset 1 of the base station)

Icon	Description
	Keypad Lock
	Voice Mail
	Silent Mode On
	Call Forward
	Do Not Disturb (DND)

Icons on the Calls Screen

Icon	Description
	Receiver Mode On
	Headset Mode On
	Handsfree Mode On
	Contact
	Call Hold
	Call Mute
	Conference Call
	Intercom Call

Icons on the Line Status Screen

Icon	Description
	Call Forward
	Do Not Disturb (DND)
	Unassigned outgoing line
	Anonymous call is enabled.
	Anonymous call rejection is enabled.

Call History Icons

Icon	Description
	Received Calls
	Missed Calls
	Placed Calls

Entering Characters on the Handset

You can enter and edit data in the corresponding field using the handset keypad. The input modes are selectable.

Topics

[Setting the Input Modes](#)

[Editing Fields](#)

[Entering Data](#)

Setting the Input Modes

The handset provides you with 12 input modes, and different input mode provides different characters.

The default input modes are Abc, 123, ABC and abc. You can enable the input modes that you used frequently and switch among them if needed.

Procedure

1. Navigate to **OK->Settings->Display->Input Method**.
2. Select a desired input mode, and then press **Change**.

Editing Fields

The limitations for some certain fields on the handset are as follow:

- **Name and Password field:** any characters
- **Number field:** only digit, dot or #
- **IP address field:** 32-bit IPv4 address or 128-bit IPv6 address

Entering Data

In corresponding input mode, you can press the keypad repeatedly to view the character (or numbers) options and press more times to highlight the desired character (or number), the available character under each key are displayed at the left bottom of the phone screen.

The following table describes how to enter different characters using the keypad keys:

If you want to	Then you can
Switch among input modes.	Press # a to switch among input modes. The current input mode is displayed at the right bottom of the phone screen.
Enter letters	Press a key one or more times (depending on what input mode you're in) to enter the possible characters that are displayed on the keypad key.
Enter special characters.	Press * # to enter the space character or the following special characters: _ " = / \ ^ ; : . , - + * # \$ % & @ ? ! ; () { } [] < > ¥ \$ £ ~ ¨ Press 0 + : • If it is in the uppercase (ABC), uppercase and lowercase (Abc) or lowercase (abc) input modes, it will provide space character and the following special characters: . , ? , ! , 0. • If it is in the numeric (123) input mode, it will only provide the digit 0. • Long press the key to enter the character +.
Delete the text.	Press ◀ or ▶ to position the cursor to the right of the text you want to delete, and then press Del to delete one character at a time or long press to delete all characters.

Related Topics

[Setting the Input Modes](#)

[Appendix B - Input Modes and Characters](#)

Customizing Your Phone

You can make your IP phone more personalized by customizing various settings.

Topics

[Turning Handset On](#)
[Turning Handset Off](#)
[Changing the Base PIN](#)
[Changing the Wallpaper](#)
[Setting the Screen Saver](#)
[Changing the Screen Brightness](#)
[Setting the Keypad Light](#)
[Changing the Language](#)
[Time & Date](#)
[Shortcuts](#)
[Handset Keypad Lock](#)
[Handset Registration](#)
[Silent Mode](#)
[Locating a Handset](#)
[Renaming the Handset](#)
[Eco Mode](#)
[Eco Mode+](#)
[Repeater Mode](#)

Turning Handset On

The handset will be turned on automatically when the battery is inserted to the handset. You can also turn the handset on manually.

Procedure

1. Do one of the following:
 - Press the On-hook key. The phone screen lights up.
 - Place the handset to the charger cradle.

Turning Handset Off

Procedure

1. Long press the On-hook key when the handset is idle.

Changing the Base PIN

To avoid unauthorized registration or access to some features on the handset, you should keep the base PIN secret. The default base PIN is "0000", you can change the default base PIN.

Procedure

1. Navigate to **OK->Settings->System Settings->Change Base PIN**.
2. Enter the system PIN (default: 0000), and then press **Done**.
3. Enter the new PIN in the **Enter New PIN** and **Re-enter New PIN** field respectively.
4. Press **Save**.

Note

We recommend that you set a new random 4-digit PIN that may not be easily guessed.

Changing the Wallpaper

You can change the wallpaper image when the handset is idle.

Procedure

1. Navigate to **OK->Settings->Display->Wallpaper**.
2. Press the navigation keys to select the desired image.
3. Press **Save**.

Setting the Screen Saver

The screen saver is designed to protect your phone screen by filling it with an analog clock. When the screen saver is enabled, an analog clock will be activated and appear on the phone screen if the handset is idle for approximately 10 seconds.

Procedure

1. Navigate to **OK->Settings->Display->Screen Saver**.
2. Press **Change**.

Changing the Screen Brightness

The handset backlight in charger or out of charger can be configured independently.

When in charger/out of charger is enabled, the backlight will be turned off after the handset is idle for about 30 minutes when the handset is or not in the charging cradle. When an incoming call arrives, a key is pressed or the the handset status changes, the backlight is automatically turned on.

Procedure

1. Navigate to **OK->Settings->Display->Display Backlight**.
2. Select the desired value from the **In Charger** or **Out Of Charger** field.
3. Press **Save**.

Setting the Keypad Light

You can enable the keypad light to illuminate the keypad keys when any key is pressed.

Procedure

1. Navigate to **OK->Settings->Display->Keypad LED**.
2. Press **Change**.

Changing the Language

The handset supports 10 languages: English, French, German, Italian, Polish, Portuguese, Spanish, Turkish, Swedish and Russian.

The default handset language is English. You can change the handset language.

Procedure

1. Navigate to **OK->Settings->Language**.
2. Select the desired language, and then press **Select**.
The phone screen prompts you whether to change the language.
3. Press **Yes**.

The handset language is changed to the selected one.

Time & Date

You can set the time and date manually. The time and date formats are also customizable.

Topics

[Setting the Time and Date Manually](#)
[Changing the Time and Date Format](#)

Setting the Time and Date Manually

If your phone cannot obtain the time and date automatically, you can set the it manually.

Before You Begin

Check with your system administrator to find out if the manual mode has been enabled.

Procedure

1. Navigate to **OK->Settings->Date & Time**.
2. Enter the date and time in the corresponding fields.
3. Press **Save**.
The time and date set on the handset will be changed accordingly.

Changing the Time and Date Format

You can customize the date with various time and date formats.

The built-in date formats are listed as below:

Date Format	Example (2016-09-02)
WWW MMM DD	Fri. Sep 02
DD-MMM-YY	02-Sep-16
YYYY-MM-DD	2016-09-02
DD/MM/YYYY	02/09/2016
MM/DD/YY	09/02/16

Date Format	Example (2016-09-02)
DD MMM YYYY	02 Sep 2016
WWW DD MMM	Fri. 02 Sep

Note

Your system administrator can customize the date format.

Procedure

1. Navigate to **OK->Settings->Display->Time Format** or **Date Format**.
2. Select the desired time format or date format.
3. Press **Change**.

Shortcuts

Shortcuts allow you to quickly and directly access the feature without scrolling through the menu when the phone is idle. For example, press the down navigation key to access Directory. You can configure six shortcuts on the phone in total.

Topics

[Supported Shortcuts](#)

[Customizing the Shortcuts](#)

Supported Shortcuts

The following table lists the default access feature of the desired shortcut, and the available access features for all shortcuts:

Shortcut	Default Access Feature	Available Access Features
Left Softkey	History	History
		Missed
		Received
Right Softkey	Line Status	Redial
		Speed Dial
		Menu
	Intercom	Line Status
		Default Line
	Directory	Call Forward
		Do Not Disturb
	Volume-	Intercom
		Directory
		Volume-
	Volume+	Volume+
		Paging
		Status

Customizing the Shortcuts

Procedure

1. Navigate to **OK->Settings->Shortcut**.
2. Select the desired shortcut, and then press **Change**.
The feature currently assigned to the selected key is highlighted and followed by a left arrow.
3. Select the desired feature, and then press **OK**.

Related Topic

[Supported Shortcuts](#)

Handset Keypad Lock

To prevent accidental use of the handset, the keypad can be locked manually by long pressing the # key. When the keypad is locked, incoming calls will still ring on your phone, but only the emergency numbers can be dialed out.

Topics

[Locking Handset Keypad](#)

[Unlocking Your Phone](#)

Locking Handset Keypad

Procedure

1. Long press the # key when the handset is idle until the phone prompts you the handset is locked.

The lock icon  appears in the status bar.

Unlocking Your Phone

Procedure

1. Long press the # key when the locked handset is idle until the phone prompts you the handset is unlocked.

The lock icon  disappears from the status bar.

Handset Registration

You can register a handset to 4 different base stations at most.

Note

Up to 8 handsets can be registered to one base station.

Topics

[Registering a Handset to a Base Station](#)

[Registering a Handset to Multiple Base Stations](#)

[Deregistering a Handset](#)

[Selecting a Base Station to Connect](#)

[Renaming the Base Station](#)

Registering a Handset to a Base Station

Before You Begin

When the phone prompts "Unregistered!", long press  on the base station till the registration LED flashes.

Procedure

1. Press the **Reg** soft key to register the handset quickly.

After the handset is registered successfully, the phone prompts "Handset Subscribed" and "Base NO. (The last 4 characters of the connected Base's MAC address)".

After the handset initializes data successfully, an icon with the internal handset number and handset name appears on the phone screen.

Tip

You can also press the **OK** soft key, select **Register Handset** and then select the desired base to register the handset. You need to enter the base PIN (default: 0000) after a base is found.

Registering a Handset to Multiple Base Stations

You can register a handset to 4 different base stations.

Before You Begin

Long press  on the base station till the registration LED flashes.

Procedure

1. Navigate to **OK->Settings->Registration->Register Handset**.
2. Select the desired base and then press **OK**.
The handset begins searching for the base.
3. Press **OK** after a base is found.
4. Enter the base PIN (default: 0000), and then press **Done** to complete registration.

After registration, the phone prompts "Handset Subscribed" and "Base NO. (The last 4 characters of the connected Base's MAC address)".

After the handset initializes data successfully, an icon with the internal handset number and handset name appears on the phone screen.

Deregistering a Handset

You may need to de-register your handset if you want to replace a base station.

Procedure

1. Navigate to **OK->Settings->Registration->De-reg. Handset**.
2. Enter the system PIN (default: 0000), and then press **Done**.
The phone screen displays the handsets names that are registered to the same base station. The name of the handset itself is highlighted and followed by a left arrow.
3. Select the desired handset, and then press **OK**.
The phone screen prompts you whether to deregister the handset.
4. Press **Yes**.

Selecting a Base Station to Connect

One handset can be registered to multiple base stations, but only one base station is the active one, and others remain saved in the list of available base stations. You can connect the handset to a desired base manually, or allow the handset to connect the base station with the best reception automatically.

Procedure

1. Navigate to **OK->Settings->Registration->Select Base**.
The phone screen displays all base stations that the handset is registered to and the **Bestbase** option. The radio box of the currently used base station with the last 4 characters of MAC address is marked.
2. Select the desired base station or **Bestbase**, and then press **Select**.
The handset begins to search for a base station. After a successful connection, the phone screen prompts "Base selected successfully!".

Renaming the Base Station

Procedure

1. Navigate to **OK->Settings->Registration->Select Base**.
2. Select a desired base station (expect **Bestbase** option), and then press **Rename**.
3. Enter the desired name in the **Rename** field.
4. Press **Save**.

Silent Mode

You can enable the silent mode if you do not want to be disturbed. The handset will not ring when receiving an incoming call, but the phone will still display the incoming call information.

Topics

[Switching on Silent Mode](#)

[Switching off Silent Mode](#)

Switching on Silent Mode

Procedure

1. Long press the * key until the phone prompts "All Ring Tones Off".
The silent icon  appears in the status bar.

Note

When the silent mode is activated, the phone will not play any advisory tones.

Related Topic

[Setting the Advisory Tone](#)

Switching off Silent Mode

Procedure

1. Long press the * key until the phone prompts "All Ring Tones On".

Locating a Handset

You can locate a misplaced registered handset using the base station.

Before You Begin

Make sure the handsets are in idle state.

Procedure

1. Press  on the base station.

All the handsets that are registered to this base station will ring (paging) simultaneously and the IP address of the base station on the phone screen will be displayed.

You can press any key on one of the handsets or press  again on the base station to stop ringing (paging).

Renaming the Handset

The handset will be named automatically if successfully registered to the base station. You can personalize the handset name.

Procedure

1. Press **OK**->**Settings**->**Handset Name**.
2. Edit the current name in the **Rename** field.

3. Press **Save**.

Eco Mode+

Eco mode+ turns off the transmission power and the radio waves emitted are virtually zero when the phone is in the standby mode. If the eco mode+ is enabled, there is no signal interaction between the handset and the base station, and the color of the signal strength indicator on the idle screen will be displayed in green. When a call arrives or a connection occurs, the phone exits the eco mode+ automatically, and the color of the signal strength indicator on the idle screen changes from green to white.

Topic

[Setting the Eco Mode+](#)

Setting the Eco Mode+

You can enable or disable the eco mode+.

Procedure

1. Navigate to **OK->Settings->System Settings->Eco Mode+**.
2. Press **Change**.
3. Enter the system PIN (default: 0000) and then press **Done**.

The phone prompts whether to reboot the base station.

4. Press **Yes**.

The base station reboots to make the change take effect. The change applies to all the handsets registered to the base station. The color of the signal strength indicator on the idle screen will change from white to green.

Eco Mode

Eco mode greatly reduces the transmission power and signal output when the phone is during a call. The attenuation range is 20m. When the distance between the base station and the handset is over 20m, the eco mode is disabled automatically.

Topic

[Setting the Eco Mode](#)

Setting the Eco Mode

You can enable or disable eco mode. If the eco mode is enabled, the radio coverage of the base station will be reduced.

Procedure

1. Navigate to **OK->Settings->System Settings->Eco Mode**.
2. Press **Change**.

Repeater Mode

Repeater mode extends the radio coverage of the base station. This feature gives you more mobility in large dwelling. If the repeater mode is enabled, and a repeater is registered to the base station, the handset registered to the base station can be used either in the base station or the repeater coverage area. It provides users with greater freedom of mobility.

For more information on how to use DECT repeater with the base station, refer to [Yealink DECT Repeater User Guide](#).

Topic

[Setting the Repeater Mode](#)

Setting the Repeater Mode

Before You Begin

Repeater mode and eco mode+ features cannot be used at the same time.

Procedure

1. Navigate to **OK->Settings->System Settings->Repeater Mode**.
2. Select a desired repeater mode and press **OK**.
The phone prompts whether to reboot the base station.
3. Press **Yes**.
The base station reboots to make the change take effect. The change is applied to all the handsets registered to the base station.

Related Topic

[Setting the Eco Mode+](#)

Audio Settings

The audio settings contain the volume settings, and the available ring tone, advisory tone and key tone settings.

Topics

[Adjusting the Volume](#)

[Setting the Ring Tone](#)

[Setting the Advisory Tone](#)

Adjusting the Volume

You can adjust the audio volume and the ring volume.

Topics

[Adjusting the Audio Volume](#)

[Adjusting the Ringer Volume](#)

Adjusting the Audio Volume

When you are during a call, you can increase or lower the volume of currently engaged audio devices (earpiece, speakerphone or Headset).

Procedure

1. Press the left or right navigation key to adjust the audio volume.

Related Topics

[Setting the Ring Tone for the External Calls](#)

[Setting the Ring Tone for the Internal Calls](#)

Adjusting the Ringer Volume

When the phone is idle or ringing, you can increase or decrease the ringer volume. If ringer volume is adjusted to the minimum, the minimum volume icon will appear on phone screen.

Procedure

1. Do one of the following:
 - Press the left or right navigation key to adjust the ringer volume.
 - Navigate to **OK->Settings->Audio->Ring Tones->Volume** to adjust the ringer volume.

Setting the Ring Tone

Ring tones are used to announce incoming calls. You can set ring tone for internal call and external call respectively.

Topics

[Setting the Ring Tone for the Internal Calls](#)

[Setting the Ring Tone for the External Calls](#)

Setting the Ring Tone for the Internal Calls

Procedure

1. Navigate to **OK->Settings->Audio->Ring Tones->Melodies**.
2. Select a desired ring tone from the **Intercom Call** field.
The ring tone is played automatically.
3. Press **Save**.

Setting the Ring Tone for the External Calls

Procedure

1. Navigate to **OK->Settings->Audio->Ring Tones->Melodies**.
2. Select the desired ring tone for a specific line.
The ring tone is played automatically.
3. Press **Save**.

Setting the Advisory Tone

Advisory tones are acoustic signals of your handset, which inform you of different actions and states. You can configure the following advisory tones independently:

- **Keypad Tone:** plays when you press any key on the keypad.
- **Confirmation:** plays when a setting is changed or the handset is placed in the charger.
- **Low Battery:** plays when the battery capacity is low and the handset needs to be charged.

Note

If the silent mode is activated, the advisory tones will not play, but you can still see the low battery and confirmation alert on the phone screen.

Procedure

1. Navigate to **OK->Settings->Audio->Advisory Tones**.
2. Select the desired value from the **Keypad Tone** field.
3. Select the desired value from the **Confirmation** field.
4. Select the desired value from the **Low Battery** field.
5. Press **Save**.

Directory

The Yealink IP phones provide several types of phone directories and what the system administrator has set for you.

The phones provide the following types of directories:

- [Local Directory](#)
- [Shared Directory](#)
- [Blacklist](#)
- [Remote Phone Book](#)

Local Directory

You can store 100 contacts in the handset's local directory, and each contact is with a name, a mobile number and an office number. The contact in the local directory can be added, edited and deleted freely.

Topics

[Adding Contacts](#)

[Editing Contacts](#)

[Deleting Contacts](#)

[Searching for Contacts](#)

Adding Contacts

You can add 100 contacts to your local directory.

Procedure

1. Navigate to **OK->Directory**.
2. Press **Options**, and then select **New Contact**.
3. Enter the name and the office, mobile or other number in the corresponding fields.
4. Press **Save**.

If the contact already exists in the local directory, the phone will prompt "Contact already exists!".

Editing Contacts

You can change or add more information to your contacts at any time.

Procedure

1. Navigate to **OK->Directory**.
2. Highlight the desired contact, and then press **Options**. Select **Edit**.
3. Edit the contact information.
4. Press **Save**.

Deleting Contacts

You can delete one or all contacts from the local directory.

Topics

[Deleting a Contact](#)

[Deleting All Contacts](#)

Deleting a Contact

Procedure

1. Navigate to **OK->Directory**.
2. Select the desired contact.
3. Press **Options**, and then select **Delete**.
The phone prompts whether to delete this contact.
4. Press **Yes**.

Deleting All Contacts

Procedure

1. Navigate to **OK->Directory**.
2. Press **Options**, and then select **Delete All**.
The phone prompts whether to delete all contacts.
3. Press **Yes**.

Searching for Contacts

In the Local Directory, you can enter search criteria to find your desired contact quickly.

Procedure

1. Navigate to **OK->Directory**.
2. Enter the name or number you are looking for in the search field.
The contacts will be displayed in the result list.

Shared Directory

All handsets that are registered on the same base station can share the contacts with each other. You can store up to 100 contacts in your phone's shared directory, and edit, delete, search or simply dial a contact from the shared directory.

Check with your system administrator to find out if this feature is available on your phone.

Topics

[Adding Shared Contacts](#)
[Editing Shared Contacts](#)
[Deleting a Shared Contact](#)
[Deleting All Shared Contacts](#)
[Searching for Shared Directory Contacts](#)
[Moving a Shared Contact to the Blacklist Directory](#)
[Moving a Shared Contact to the Local Directory](#)
[Placing a Call from the Shared Directory](#)

Adding Shared Contacts

Procedure

1. Navigate to **OK->Directory->Shared Directory**.
2. Select **Options** and then select **New Contact**.
3. Enter the name and the office, mobile or other number in the corresponding fields.
4. Press **Save**.

If the contact already exists in the shared directory, the phone will prompt "Contact already existed!".

Editing Shared Contacts

Procedure

1. Navigate to **OK->Directory->Shared Directory**.
2. Highlight a contact and then press **Options**.
3. Select **Edit**.
4. Edit the shared contact information.
5. Press **Save**.

Deleting a Shared Contact

Procedure

1. Navigate to **OK->Directory->Shared Directory**.
2. Highlight a contact and then press **Options**.
3. Select **Delete**.
The phone prompts whether to delete the contact.
4. Press **Yes** to delete.

Related Topic

[Deleting All Shared Contacts](#)

Deleting All Shared Contacts

Procedure

1. Navigate to **OK->Directory->Shared Directory**.
2. Highlight a contact and then press **Options**.
3. Select **Delete All**.
The phone prompts whether to delete all contacts.
4. Press **Yes** to delete.

Related Topic

[Deleting a Shared Contact](#)

Searching for Shared Directory Contacts

In the Shared Directory, you can enter search criteria to find your desired contact quickly.

Procedure

1. Navigate to **OK->Directory->Shared Directory**.
2. Enter the name or number you are looking for in the search field.

The contacts will be displayed in the result list.

Moving a Shared Contact to the Local Directory

Procedure

1. Navigate to **OK->Directory->Shared Directory**.
2. Select a contact.
3. Press **Options** and then select **Add To Local**.
4. Select **New Entry**.
5. Press **Save**.

Placing a Call from the Shared Directory

Procedure

1. Navigate to **OK->Directory->Shared Directory**.
2. Select the desired contact.
3. Press the Off-hook key.

If the selected contact has multiple numbers, select the desired number, and press OK.

Related Topic

[Searching for Shared Directory Contacts](#)

Blacklist

Incoming calls from the blacklist contacts are rejected automatically. You can store 30 contacts in the blacklist to block unwanted callers.

Topics

[Adding a Blacklist Contact](#)

[Editing a Blacklist Contact](#)

[Deleting Blacklist Contacts](#)

Adding a Blacklist Contact

Procedure

1. Navigate to **OK->Settings->Telephony->Blacklist**.
2. Press **Options**, and then select **New Entry**.
3. Enter the blacklist number.
4. Press **Save**.

Editing a Blacklist Contact

You can edit your blacklist contacts at any time.

Procedure

1. Navigate to **OK->Settings->Telephony->Blacklist**.
2. Highlight the desired blacklist contact, and then press **Options**. Select **Edit**.

3. Edit the blacklist contact information.
4. Press **Save**.

Deleting Blacklist Contacts

You can delete one or all blacklist contacts.

Topics

[Deleting a Blacklist Contact](#)

[Deleting all Blacklist Contacts](#)

Deleting a Blacklist Contact

Procedure

1. Navigate to **OK->Settings->Telephony->Blacklist**.
2. Select the desired blacklist contact.
3. Press **Options**, and then select **Delete**.

Deleting all Blacklist Contacts

Procedure

1. Navigate to **OK->Settings->Telephony->Blacklist**.
2. Press **Options**, and then select **Delete All**.
The phone prompts whether to delete all contacts.
3. Press **Yes** to delete.

Remote Phone Book

If the Remote Phone Book feature has been enabled by your system administrator, you can access your corporate directory directly from your phone. You can simply dial a contact from the corporate directory. You can also search for a contact or add contacts from the remote phone book to the local directory.

You can only access up to 5 remote phone books on your phone. Check with your system administrator to find out if this feature is available.

Topics

[Searching for Remote Phone Book Contacts](#)

[Adding a Remote Phone Book Contact to the Local Directory](#)

Searching for Remote Phone Book Contacts

In the Remote Phone Book, you can enter search criteria to find your desired contact quickly.

Procedure

1. Navigate to **OK->Directory->Remote Directory**.
2. Select the desired remote phone book.
3. Enter the name or number you are looking for in the search field.
The contacts will be displayed in the result list.

Adding a Remote Phone Book Contact to the Local Directory

You can add contacts in the remote phone book to the local directory. The contact you add from the remote phone book will not disappear from your local directory, even if your system administrator deletes this contact from the remote phone book.

Procedure

1. Navigate to **OK->Directory->Remote Directory**.
2. Select the desired remote phone book.
3. Highlight the desired contact, and then press **Options**.
4. Select **Add To Local->New Entry**.
5. Edit the corresponding fields.
6. Press **Save**.

Tip

You can select **Add To Local->Update Existing** to add the number to an existing contact or update the existing contact information.

Call History

The IP phones maintain call history lists of Missed Calls, Placed Calls and Received Calls.

Topics

[Viewing History Records](#)

[Adding a History Record to Local Directory](#)

[Adding a History Record to Blacklist](#)

[Deleting History Records](#)

Viewing History Records

You can view a list of up to 100 Missed Calls, Placed Calls and Received Calls.

Procedure

1. Press **History**.
The phone screen displays all call records.
2. Press **Options**, and then select **Detail**.
The detailed information of the entry appears on the phone screen.

Adding a History Record to Local Directory

You can add a history record to the local directory.

Procedure

1. Press **History**.
The phone screen displays all call records.
2. Highlight the desired entry, and then press **Options**.
3. Select **Add To Local->New Entry**.
4. Edit the corresponding fields.
5. Press **Save**.

Tip

You can select **Add To Local->Update Existing** to add the number to an existing contact or update the existing contact information.

Adding a History Record to Blacklist

You can add a history record to Blacklist.

Procedure

1. Press **History**.
The phone displays all call records.
2. Select the desired list.
3. Highlight the desired entry, and then press **Options**.
4. Select **Add To Blacklist**.
The phone prompts whether to add it or not.

5. Press **Yes**.

Deleting History Records

You can delete one or all call records from the call history list.

Topics

[Deleting a Call Record](#)

[Deleting All Call Records](#)

Deleting a Call Record

Procedure

1. Press **History**.
The phone displays all call records.
2. Highlight the desired entry, and then press **Options->Delete**.

Deleting All Call Records

Procedure

1. Press **History**.
The phone displays all call records.
2. Select the desired list.
3. Press **Options**, and then select **Delete All**.
The phone prompts whether to delete all the records.
4. Press **Yes** to delete.

Call Features

You can place a call, answer a call, transfer a call, etc. on Yealink IP phone.

Topics

[Switching Among the Receiver, Handsfree and Headset Modes](#)

[Changing the Default Outgoing Line](#)

[Placing Calls](#)

[Answering Calls](#)

[Silencing or Rejecting Incoming Calls](#)

[Ending Calls](#)

[Muting/Unmuting Audio](#)

[Call Hold](#)

[Do Not Disturb \(DND\)](#)

[Call Forward](#)

[Transferring Calls](#)

[Conference Calls](#)

[Multicast Paging](#)

Switching Among the Receiver, Handsfree and Headset Modes

You can place a call using the following call modes:

- Receiver mode—pressing the Off-hook key to dial out.
- Earpiece mode—pressing the Speakerphone key to dial out.
- Headset mode—connecting a standard 3.5mm headset.

Changing the Default Outgoing Line

Your system administrator can assign one or more outgoing lines for the handset. Only the outgoing line(s) assigned by your system administrator can be used to place calls.

When multiple outgoing lines are assigned to the handset, the first one will be the default outgoing line. You can change the default outgoing line of the handset.

Procedure

1. Navigate to **OK->Settings->Telephony->Default Line**.

The phone displays all the assigned outgoing lines. The default outgoing line is highlighted and followed by a left arrow.

2. Highlight the desired line, and then press **OK**.

The default outgoing line is changed successfully.

Placing Calls

When the handset is registered to the base station successfully, you can use your handset to place an internal or external call. One handset can handle a maximum of 2 calls at one time, and one call is active (the call that has audio associated with it), while the other is placed on hold.

By default, the phone uses the default outgoing line to place a call.

Note

The base station can handle a maximum of eight narrow-band calls, or four wide-band calls. For more information, contact your system administrator.

Topics

[Placing Internal Calls](#)
[Placing External Calls](#)
[Placing a Call from the Call History](#)
[Placing a Call from the Directory](#)
[Placing a Call with a Speed Dial Key](#)
[Redialing a Number](#)
[Placing an Anonymous Call](#)

Placing Internal Calls

Intercom is a useful feature in the office to quickly contact with the operator or the secretary. Internal intercom calls are made between handsets registered to the same base station.

Topics

[Setting Auto Intercom](#)
[Placing an Internal Call](#)
[Placing an Internal Call During an External Call](#)

Setting Auto Intercom

The following types of auto intercom feature are available:

- **On (Beep On):** The handset answers an internal intercom call automatically and plays a warning tone.
- **On (Beep Off):** The handset answers an internal intercom call automatically without a warning tone.
- **Off:** Auto intercom feature is off. You need to answer an internal intercom call manually.

Procedure

1. Navigate to **OK->Settings->Telephony->Auto Intercom**.
2. Select the desired option, and then press **Change**.

Placing an Internal Call**Procedure**

1. Navigate to **OK->Intercom**.
2. Select the desired handset or **All Handsets**.
If you select **All Handsets**, all other subscribed handsets will ring simultaneously.
3. Press **OK**, Speakerphone key or Off-hook key.

Tip

During an external call, you can press **Options->Intercom** to place an internal call.

Placing an Internal Call During an External Call**Procedure**

1. Press **Options->Intercom**.
2. Select the desired handset, and then press **OK**.

Placing External Calls

You can place external calls on the handset. External calls based on the public telephone network require the SIP lines.

Note

Your system administrator needs to assign the SIP line as the outgoing line for the handset beforehand.

Topics

[Placing an External Call](#)

[Placing Multiple External Calls](#)

Placing an External Call

Procedure

1. Do one of the following:
 - Enter the desired number using the keypad.
 - Press the Speakerphone key to enter the pre-dialing screen.
Enter the desired number using the keypad.
2. Press **OK**, Speakerphone key or Off-hook Key to dial out.

Tip

You can make an IP call by directly dialing the IP address of any IP phone. For example, you can enter 192*168*1*15 to dial the IP 192.168.1.15.

Placing Multiple External Calls

When you are in a call, you can hold your current call and place a new call.

Procedure

1. Press **New Call**.
2. Enter the contact number.
3. Press the **OK**, Speakerphone key or Off-hook key.

Note

You can press **Options**, and then select a contact from the directory to dial out.

Placing a Call from the Call History

You can place calls to the contact from the Call History list.

Procedure

1. Press **History**.
The phone screen displays all call records.
2. Select the desired call record, and press the Off-hook key.

Placing a Call from the Directory

You can call contacts from your phone directories.

Procedure

1. Navigate to **OK->Directory**.
2. Select the desired contact, and press the Off-hook key.
If the selected contact has multiple numbers, select the desired number, and press **OK**.

Related Topic

[Searching for Contacts](#)

Placing a Call with a Speed Dial Key

You can quickly dial a number by using a speed dial key without entering the directory.

Topics

[Assigning a Speed Dial Number](#)

[Changing a Speed Dial Number](#)

[Deleting a Speed Dial Number](#)

[Calling a Contact Using a Speed Dial Key](#)

Assigning a Speed Dial Number

You can assign a contact number as a speed dial number to the digit key. A maximum of 8 speed dial numbers are allowed.

Before You Begin

The assigned number should exist in the directory.

Procedure

1. Navigate to **OK->Settings->Telephony->Speed Dial**
The phone screen displays all available speed dial keys (2-9).
2. Select the desired digit key, and then press **Assign**.
3. Select the desired contact from the directory.
4. Press **OK** to assign the number to the selected speed dial key.
If the selected contact has multiple numbers, select a desired number, press **OK**.

Changing a Speed Dial Number

Before You Begin

The assigned number should exist in the directory.

Procedure

1. Navigate to **OK->Settings->Telephony->Speed Dial**.
2. Select an assigned speed dial key.
3. Press **Options**, and then select **Change**.
4. Select a contact number from the directory.
5. Press **OK** to change the assigned speed dial number.

Deleting a Speed Dial Number

Procedure

1. Navigate to **OK->Settings->Telephony->Speed Dial**.
2. Select a desired speed dial key.
3. Press **Options**, and then select **Clear Key**.

Calling a Contact Using a Speed Dial Key

Procedure

1. Long press the speed dial key (digit key 2-9) when the handset is idle.
The number assigned to this speed dial key is dialed out.

Redialing a Number

The redial list stores the last twenty dialed phone numbers. When the memory of the redial list is full, the handset will automatically erase the oldest one when a new number is dialed. You can redial a call from the redial list.

Topics

[Redialing a Previously Dialed Number](#)

[Redialing the Last Dialed Number](#)

[Adding a Dialed Number to Local Directory](#)

[Deleting a Redial Record](#)

[Deleting All Redial Records](#)

Redialing a Previously Dialed Number

Procedure

1. Press the Off-hook key when the handset is idle to access the redial list.
2. Select a record.
3. Press the Off-hook key or Speakerphone key to dial out.

Tip

Before placing an external call, you can press **Options->Edit Before Call** to edit the phone number.

Redialing the Last Dialed Number

Procedure

1. Press the Off-hook key twice when the handset is idle.
A call to your last dialed number is attempted.

Adding a Dialed Number to Local Directory

You can add a dialed external call number to a local directory or update the number for an existing contact.

Procedure

1. Press the Off-hook key when the handset is idle to access the redial list.
2. Select the desired record.
3. Press **Options**, and then select **Add To Local->New Entry**.

4. Select the type you want to add the number to.
5. Edit the corresponding fields.
6. Press **Save**.

Tip

You can select **Add To Local**->**Update Existing** to add the number to an existing contact or update the existing contact information.

Deleting a Redial Record

Procedure

1. Press the Off-hook key when the handset is idle to access the redial list.
2. Select a record.
3. Press **Options**, and then select **Delete**.

Deleting All Redial Records

Procedure

1. Press the Off-hook key when the handset is idle to access the redial list.
2. Press **Options**, and then select **Delete All**.
The phone prompts whether to delete all records.
3. Press **Yes**.

Placing an Anonymous Call

You can place a call to someone without revealing your identification by blocking your name or phone number from being displayed to the recipient.

Note

Anonymous call is not available on all servers. Check with your system administrator to find out if this feature is available on your phone.

You need to enable anonymous call for a specific line first, and then place calls in this line.

Topics

[Enabling Anonymous Call](#)

[Placing an Anonymous Call](#)

Enabling Anonymous Call

Procedure

1. Navigate to **OK**->**Call Features**->**Anonymous Call**.
2. Select the desired line.
The phone screen displays the outgoing lines currently assigned to the handset. The default outgoing line is highlighted and followed by a left arrow.
3. Select **Enabled** from the **Status** field.

Placing an Anonymous Call

Before You Begin

Enable anonymous call for a specific line.

Procedure

1. Select the anonymous line to place a call.

The callee is prompted with an incoming call from anonymity.

If the callee enables anonymous rejection feature, you may be prompted that the callee does not accept calls from an anonymous number.

Related Topics

[Enabling Anonymous Call](#)

[Rejecting Anonymous Calls Automatically](#)

Answering Calls

When you receive a call, you can choose to manually answer it or answer it automatically.

Topics

[Assigning Incoming Lines to the Handset](#)

[Answering a Call](#)

[Answering a Call When in a Call](#)

[Answering a Call Automatically](#)

Assigning Incoming Lines to the Handset

You can assign one or more incoming lines for the handset. The handset can only receive incoming calls of the assigned incoming line(s).

Procedure

1. Navigate to **OK->Settings->Telephony->Incoming Lines**.

2. Enter the system PIN (default: 0000), and then press **Done**.

The phone screen displays all registered handsets. The handset itself is highlighted and followed by a left arrow.

3. Select the desired handset.

4. Select **Accept** from the desired line fields.

5. Press **Save**.

Answering a Call

Procedure

1. Do one of the following:

- Press the Off-hook key, Speakerphone key or **Accept**.
- Press the Speakerphone key.
- If a headset is connected, press **Accept**.

Related Topic

[Switching Among the Receiver, Handsfree and Headset Modes](#)

Answering a Call When in a Call

When you are in an active call and an incoming call arrives on the phone, the call waiting tone beeps, and the incoming call information is displayed.

Before You Begin

Enable call waiting feature on the phone.

Procedure

1. Press the down navigation key to select the incoming call.
2. Press OK, the Off-hook key, the Speakerphone key or **Accept**.
The active call is placed on hold, and the incoming call becomes active.

Related Topic

[Enabling Call Waiting](#)

Enabling Call Waiting

Call waiting enables you to receive another call when there is already an active call on your phone. If it is disabled, the new incoming call will be rejected automatically.

You can enable call waiting feature to avoid missing important calls during a call. You can also set the phone to play a warning tone when the new incoming call arrives.

Procedure

1. Navigate to **OK->Call Features->Call Waiting**.
2. Select **Enabled** from the **Status** field.
3. Select **Enabled** from the **Tone** field.

Answering a Call Automatically

When the handset is placed in the charger, you can simply answer the incoming calls by picking up the handset from the charger without pressing the Off-hook key.

Procedure

1. Navigate to **OK->Settings>Telephony->Auto Answer**.
2. Press **Change** to check the **Auto Answer** checkbox (the default status is checked).

Silencing or Rejecting Incoming Calls

When you receive an incoming call, you can choose to silence or reject the call instead of answering.

Topics

[Silencing a Call](#)

[Rejecting a Call Manually](#)

[Rejecting Anonymous Calls Automatically](#)

Silencing a Call

You can silence a call to stop your phone from ringing. Even if you silence the call, the incoming call notification continues to display on your phone.

Procedure

1. Press **Silence**.

Rejecting a Call Manually

Procedure

1. Press the On-hook key to reject an incoming call.

Rejecting Anonymous Calls Automatically

You can set your phone to automatically reject incoming calls from callers who have withheld their caller ID information (including the name or phone number). As a result, your phone will not ring and you will not be notified of an attempted call.

Procedure

1. Navigate to **OK->Call Features->Anon.Call Rejection**.

The phone screen displays the incoming lines currently assigned to the handset. The default incoming line is highlighted and followed by a left arrow.

2. Select the desired line.
3. Select **Enabled** from the **Status** field.
4. Press **Save**.

When the caller has anonymous call feature enabled and places a call to your IP phones, the call is automatically rejected.

Related Topic

[Placing an Anonymous Call](#)

Ending Calls

Procedure

1. Press  or **End**.

Muting/Unmuting Audio

You can mute the microphone temporarily during a call.

Procedure

1. Press the Mute key during an active call.
The call is muted, and the mute icon  is displayed on the phone screen.
2. Press the Mute key again.
3. The mute icon  disappears from the phone screen.

Call Hold

You can place an active call on hold and resume the call when you are ready. When you place a call on hold, your IP PBX may play music to the other party while waiting.

Topics

[Holding a Call](#)

[Resuming a Held Call](#)

[Swapping Between Active and Held Calls](#)

Holding a Call

Procedure

1. Press **Options** during a call, and then select **Hold**.
The phone screen indicates that the call is on hold.

Resuming a Held Call

Procedure

1. Press **Resume**, the Speakerphone key or Off-hook key.
If multiple calls are placed on hold, select the desired call first.

Swapping Between Active and Held Calls

You can easily switch between active and held calls.

Procedure

1. Do one of the following to swap the active and held calls:
 - If the call is active, press the **Swap** soft key.
 - Press the up or down navigation key.

Do Not Disturb (DND)

DND enables your phone to reject all incoming calls automatically when you do not want to be interrupted. You can enable DND for specific lines.

Note

Check with your system administrator to find out if the DND feature is available on your phone.

Topics

[Rejecting Calls with DND](#)

Rejecting Calls with DND

You can activate DND for specific lines. The phone will reject all incoming calls automatically.

Procedure

1. Press **OK**->**Call Features**->**Do Not Disturb**.
The phone screen displays the incoming lines currently assigned to the handset. The default incoming line is highlighted and followed by a left arrow.
2. Select the desired line, and then press **OK**.
3. Select **Enabled** from the **Status** field.
4. Press **Save**.

The DND icon  in the status bar indicates the DND mode is activated. You can press the **Line** soft key when the handset is idle to check the line status.

Call Forward

You can enable call forward feature on a per-line basis. The handset will forward incoming calls of the line to another party.

There are three forwarding types:

- **Always Forward:** Incoming calls are immediately forwarded. There is no prompts on the phone screen when the line receives an incoming call. The incoming call is logged in the **Received Calls** list.
- **Busy Forward:** Incoming calls are forwarded when the line is busy.
- **No Answer Forward:** Incoming calls are forwarded if not answered after a period of time.

Topic

[Forwarding Incoming Calls](#)

Forwarding Incoming Calls

Procedure

1. Navigate to **OK->Call Features->Call Forward**.
The phone screen displays the assigned incoming lines. The default incoming line is highlighted and followed by a left arrow.
2. Select the desired line.
3. Select the desired forwarding type.
4. Select **Enabled** from the **Status** field.
5. Enter the destination number you want to forward incoming calls to in the **Target** field.
6. If you select the **No Answer Forward**, select the desired ring time to wait before forwarding from the **After Ring Time** field.
7. Press **Save**.

The forward icon  in the status bar indicates call forward feature is enabled.

The incoming calls will be forwarded to the destination number according to your setting.

Note

Call forward feature may be overridden by the server settings. For more information, contact your system administrator.

Transferring Calls

During a call, you can transfer the call to another contact in one of three ways:

- **Blind Transfer:** Transfer a call directly to the third party without consulting.
- **Semi-Attended Transfer:** Transfer a call when receiving ringback.
- **Attended Transfer (Consultative Transfer):** Transfer a call with prior consulting.

Topics

[Performing a Blind Transfer](#)

[Performing a Semi-Attended/Attended Transfer](#)

Performing a Blind Transfer

You can transfer a call to another contact immediately without consulting with her/him first.

Procedure

1. Press **Options**->**Transfer**, or the TRAN key.
2. Enter the number you want to transfer to.
3. Press TRAN or **Transfer** to complete the transfer.

Performing a Semi-Attended/Attended Transfer

You can transfer a call to another contact immediately when receiving ringback or after consulting with her/him first.

Procedure

1. Press **Options**->**Transfer**, or the TRAN key during a call.
2. Enter the number you want to transfer to.
3. Press the OK key, Off-hook key or Speakerphone key.
3. Do one of the following:
 - When you hear the ringback tone, press the TRAN key or **Transfer** to finish a semi-attended transfer.
 - After the contact answers the call, press the TRAN key or **Transfer** to finish an attended transfer (consultative transfer).

Conference Calls

The Yealink IP phones support creating a conference with other two external parties (or an external and an internal party) and multi-way network conference.

Note

Network conference is not available on all servers. Check with your system administrator to find out if it is available on your phone.

Topics

[Local Conference](#)

[Network Conference](#)

Local Conference

The IP phones support three-way (including yourself) conference call, it is the default conference type called Local Conference. You can set up a conference between an active call and a held call at any time.

Topics

[Setting Up a Local Conference Call](#)

[Joining Two Calls in a Conference](#)

[Muting or Unmuting a Conference Call](#)

[Ending a Conference Call](#)

Setting Up a Local Conference Call

Procedure

1. Place a call to the first party.
2. When the first party answers the call, press **Options**->**Conference** to place a new call.
3. Enter the number of the second party to dial out.
The active call is placed on hold.
4. When the second party answers the call, press **Conf.** again to join all parties in the conference.

Joining Two Calls in a Conference

You can invite a held call into a conference call with the active call.

Procedure

1. Place two calls using the same or different accounts on the phone.
2. Select the desired call for a conference and ensure that the call is active.
3. Press **Options**->**Conference**.

Muting or Unmuting a Conference Call

You can mute the local microphone during a conference call so that the other two participants can hear each other except you.

Procedure

1. Press the MUTE key to mute the conference.
2. Press the MUTE key again to unmute the conference.

Ending a Conference Call

Procedure

1. The conference initiator presses the On-hook key or **End**.
If any party in the conference ends the call, the other parties remain connected.

Network Conference

If your system administrator has set a network conference feature on your phone, you can initiate a conference with multiple participants.

Topic

[Setting Up a Network Conference](#)

[Inviting another Party into an Active Conference Call](#)

[Holding/Resuming a Conference Call](#)

[Ending a Conference Call](#)

Setting Up a Network Conference

Procedure

1. Place a call to the first party.
2. Press **Options**->**Conference** to place a new call.
The active call is placed on hold.
3. Enter the number of the second party, and then press the OK key or **Conf.**
4. When the second party answers the call, press **Conf.** to add the second party to the conference.
5. Press **Conference** to place a new call.

The conference call is placed on hold.

6. Enter the number of the new party, and then press the OK key or **Send**.
7. When the new party answers the call, press **Conf.** to add the new party to the conference.
8. Repeat steps 5 to 7 until you add all parties.

Note

The procedures for setting up a network conference call on specific servers may be different. Contact your system administrator for more information.

Inviting another Party into an Active Conference Call

Any party in the conference call can invite other party into an active conference call.

Procedure

1. Press **New Call**.
2. Enter the desired number and dial out.
3. When the new party answers the call, press **Options**, and then select **Conference**.
The new party is joined to the conference call.

Holding/Resuming a Conference Call

Procedure

1. Any party in the conference call press **Options**, and then select **Hold**.
The party will only place himself/herself on hold. Other parties can continue the conference call normally. The conference call will only be held when all parties in the conference call place themselves on hold.

Ending a Conference Call

Procedure

1. The conference initiator presses the On-hook key or **End**.
If any party in the conference ends the call, the other parties remain connected.

Multicast Paging

Multicast Paging allows you to easily and quickly broadcast instant audio announcements to users who are listening to a specific multicast group on a specific channel.

The IP phone supports the following 31 channels:

- **0**: Broadcasts are sent to channel 0.
- **1 to 25**: Broadcasts are sent to channel 1 to 25. We recommend that you specify these channels when broadcasting with Polycom IP phones which have 25 channels you can listen to.
- **26 to 30**: Broadcasts are sent to channel 26 to 30. We recommend that you specify these channels when broadcasting with Yealink IP phones

Note that all IP phones in the multicast paging group must be deployed in the same network, since a broadcast is used. The IP phone can only send/receive broadcasts to/from the listened channels. Other channels' broadcasts will be ignored automatically by the IP phone.

Topics

[Sending Multicast Paging](#)

[Receiving Multicast Paging](#)

Managing a Paging Call

Sending Multicast Paging

Before You Begin

Your system administrator has set the paging group for your phone.

Procedure

1. Navigate to **OK->Call Features->Paging**.
2. Select the desired paging group.
3. Press **Paging**.

Note

Multicast RTP is one way only from the sender to the multicast address(es) (receiver). For outgoing RTP multicasts, all other existing calls on the phone will be placed on hold.

Receiving Multicast Paging

Your system administrator has set a listening paging group for you, and then you can receive a paging call when the phone is idle. The paging call is automatically answered on your phone.

When there is a voice call or a paging call in progress, the phone handles the new paging call differently according to the multicast listening settings configured by your system administrator.

Managing a Paging Call

During a paging call, you can do the following:

- Press **Hold** to place the current paging call on hold.
The paging call is placed on hold and the receiver releases the session.
- Press **Resume** to resume the held paging call.
The multicast RTP session is re-established.
- Press **End Call** to end the paging call.

Advanced Features

This chapter introduces how to use the advanced features on the IP phone.

Topics

[Call Park and Call Retrieve](#)

[Shared Line](#)

[Voice Mail](#)

If you require additional information or assistance with your new phone, contact your system administrator.

Call Park and Call Retrieve

You can use this feature to park a call, and then retrieve the call either from your phone or another phone. After you park a call, the call is placed on hold, you can continue the conversation after retrieving it.

The IP phone supports this feature under the following modes:

- **FAC mode:** park the call to the local extension or a desired extension through dialing the park code.
- **Transfer mode:** park the call to the shared parking lot through a blind transfer. For some servers, the system will return a specific retrieve park number (park retrieve code) from which the call can be retrieved after parking successfully.

Note

Call park is not available on all servers. Check with your system administrator to find out if it is available on your phone.

Topics

[Parking or Retrieving a Call in the FAC Mode](#)

[Parking or Retrieving a Call in the Transfer Mode](#)

[Retrieving a Call with a Retrieve Key](#)

Parking or Retrieving a Call in the FAC Mode

Your system administrator sets the FAC mode in which you can park and retrieve a call on your phone.

Topics

[Parking a Call](#)

[Retrieving a Parked Call in the FAC Mode](#)

Parking a Call

Before You Begin

Your system administrator has set call park in the FAC mode.

Procedure

1. During a call, press **Options**, and then select **Call Park**.
The phone will dial the call park code which is pre-configured.
2. Do one of the following:

- If you want to park the call against the local extension, press the # key.
- If you want to park the call against the desired extension, enter the extension (for example, 4606) where you want to park the call and press the # key.

If the call is parked successfully, you will hear a voice prompt that the call is parked.

Retrieving a Parked Call in the FAC Mode

Before You Begin

Your system administrator has set call park in the FAC mode. There is a call parked on the extension. Get the park retrieve code from your system administrator.

Procedure

1. Dial the park retrieve code.
2. Follow the voice prompt to retrieve:
 - Press the # key on the phone where the call is parked.
 - Enter the desired extension followed by # (for example, 4606#) on any phone.

Related Topic

[Retrieving a Call with a Retrieve Key](#)

Parking or Retrieving a Call in the Transfer Mode

Your system administrator has set the Transfer mode in which you can park and retrieve a call on your phone.

Topics

[Parking a Call in the Transfer Mode](#)

[Retrieving a Parked Call in the Transfer Mode](#)

Parking a Call in the Transfer Mode

Before You Begin

Your system administrator has set call park in the Transfer mode.

Procedure

1. During a call, press **Options**, and then select **Call Park**.
The call will be directly transferred to the shared parking lot.

Retrieving a Parked Call in the Transfer Mode

Before You Begin

Your system administrator has set call park in the Transfer mode. There is a call parked on the shared parking lot.

Procedure

1. Dial the retrieve lot.
The phone will retrieve the parked call from the shared parking lot.

Tip

When the phone is idle, you can use a Retrieve key to retrieve a parked call directly.

Related Topic

[Retrieving a Call with a Retrieve Key](#)

Retrieving a Call with a Retrieve Key

You can easily use a retrieve key to retrieve a parked call quickly.

Topics

[Setting a Retrieve Key](#)

[Retrieving a Call with a Retrieve Key](#)

Setting a Retrieve Key

You can set a shortcut key as Retrieve key.

Before You Begin

Check with your system administrator if the FAC or Transfer mode is set on your phone.

Procedure

1. Navigate to **OK->Settings->Shortcut**.
2. Select the desired shortcut key, and then press **Change**.
3. Select **Retrieve**, and then press **OK**.

Retrieving a Parked Call using a Retrieve Key

Before You Begin

1. There is a call parked on the extension or the shared parking lot.
2. You need to set a Retrieve key.
3. Your system administrator has set call park feature for your phone.

Procedure

1. Press the Retrieve key when the handset is idle.
The handset will dial the configured park retrieve code.

Related Topic

[Setting a Retrieve Key](#)

Shared Line

Yealink IP phone supports using Shared Call Appearance (SCA) to share a line. So that this line can be registered on more than one IP phone at the same time.

Your system administrator can set your phone to use shared line.

Note

Check with your system administrator to find out if SCA is available on your phone.

Topics

[Placing Calls on a Shared Line](#)

[Answering Calls on a Shared Line](#)


[Placing a Call on Public Hold](#)

[Retrieving a Held Call Remotely on a Shared line](#)

[Pulling a Shared Call on a Shared line](#)

State Indicator of Shared Line

If your system administrator assigns the shared line to your handset, the SCA with an icon is displayed on right soft key.



The following table shows the icon associated with the shared line:

Icons	Description
	The shared line is idle.
	The shared line is dialing, in conversation or placed on private hold.
 (Flashing)	The shared line receives an incoming call or is placed on public hold.

Placing Calls on a Shared Line

You can have one or multiple calls on a shared line. The phone places a call on the first shared line automatically. You can press **SCA** to select the desired shared line.

Related Topic

[Placing Calls](#)

Answering Calls on a Shared Line

When an incoming call arrives on the shared line, all the registered phones will ring simultaneously, and the call can be answered on any one of the phones. You can answer one or two calls on the shared line.

Related Topic

[Answering Calls](#)

Placing a Call on Public Hold

You can place a call on public hold that any shared line phone can retrieve the held call.

Procedure

1. During a call, press **Options**, and then select **Hold**.

The call is held on your phone, and all of the phones registered with shared line show the call is in a held state.

Placing a Call on Private Hold

In SCA scenario, you can place a call on private hold that only you can retrieve the held call.

Topics

[Setting a Private Hold Key](#)

[Holding a Call Privately](#)

Retrieving a Held Call Remotely on a Shared line

If you place a call on hold on a shared line, you can resume this call at any time. When the shared line key shows a call that is in a held state, you can resume the held call remotely from other user's phone.

Before You Begin

There is at least one call placed on public hold on the shared line.

Procedure

1. Press **SCA**, and then select the held call.
2. Press **Resume**.

Barging In an Active Call on a Shared line

In SCA scenario, both you and other users can barge into an active call on the shared line. Only one user can barge into a call at a time. After a user barges into a call, the call turns into a three-party conference.

Before You Begin

There is at least one active call on the shared line.

Procedure

1. Press **SCA**, and then select an active call.
2. Press **BargeIn** to interrupt the active call.

Pulling a Shared Call on a Shared line

In SCA scenario, both you and other users can pull an existing call from another shared phone that is active or held.

Before You Begin

There is an active or held call on the shared line. Contact your system administrator for the call pull feature access code.

Procedure

1. Enter the call pull feature access code (for example, *11).
2. Press OK, Speakerphone key or Off-hook key.

Voice Mail

Voice Mail feature allows you to leave voice mails for someone or listen to your voice mail messages on your IP phones. This feature is set up on the server side and not all servers support this feature.

Topics

[Setting the Voice Mail Code](#)

[Leaving Voice Mails](#)

[Listening to Voice Mails](#)

[Setting a Voice Mail Key for a Specific Line](#)

Setting the Voice Mail Code

If you want to connect your phone to the message center, you need to set the voice mail code on your phone.

Before You Begin

1. Navigate to **OK->Voice Mail->Set Voice Mail**.
2. Select the desired line, and then press **Select**.
3. Select **Enabled** from the **Status** field.
4. Enter voice mail code in the **Number** field.
5. Press **OK**.

Setting a Voice Mail Key for a Specific Line

You can set digit key 1 as a voice mail key for a specific line. When the handset is idle, you can long press this key, and quickly access the voice mails without scrolling through the menu.

Procedure

1. Navigate to **OK->Voice Mail->Set Key 1**.
2. Select the desired line, and then press **Select**.

Leaving Voice Mails

You can leave a voice mail to someone when he or she is busy or inconvenient to answer the call. Follow the voice prompts from the system server to leave a voice mail, and then hang up.

Listening to Voice Mails

Before You Begin

You need to set the voice mail code in advance.

Procedure

1. Navigate to **OK->Voice Mail->Play Message** or press **Message** key.
2. Select the desired line, and then press **Select**.
The handset dials out the voice mail code using the selected line automatically.
3. Follow the voice prompt from the system server to listen to your voice mails.

Tip

If you have set a voice mail key, you can long press the Voice Mail key to access the voice mail of a specified line.

Related Topics

[Setting the Voice Mail Code](#)

[Setting a Voice Mail Key for a Specific Line](#)

Maintaining Your Phone

When your phone cannot operate properly, you need to investigate or troubleshoot issues among other tasks your administrator may ask you to perform.

Topics

[Investigating Warnings](#)

[Restarting the Base Station](#)

[Resetting the Base Station](#)

[Resetting the Handset](#)

[Triggering the Auto Provisioning](#)

Investigating Warnings

When the default password is used on the IP phones, you can view the warning details about the issue from **Status** screen.

Procedure

1. Navigate to **OK->Status->Base**.

The warning detail is displayed in the **Warning** field.

Related Topics

[Clearing Warnings](#)

[Changing the Administrator Password](#)

Restarting the Base Station

The improper operation may cause malfunction. If a malfunction occurs, your system administrator may ask you to restart the base station to refresh the settings.

Procedure

1. Navigate to **OK->Settings->System Settings->Base Restart**.
2. Enter the system PIN (default: 0000), and then press **Done**.

After the above steps, the registration LED and network status LED go out simultaneously. After a period of time, the LED indicators will glow green again when the base station restarts successfully.

Resetting the Base Station

Generally, some common issues may occur while using the IP phone. Your system administrator may ask you to reset your phone to factory after you have tried all troubleshooting suggestions but still do not solve the problem. Resetting will delete all your personal settings, and reset all settings to the factory defaults. Check with your system administrator if the personalized settings are kept before resetting your phone to factory.

Note

This will clear all individual settings of the base station (e.g., directory and account registrations). Handset registrations and the system PIN will not be reset to factory defaults.

Procedure

1. Navigate to **OK->Settings->System Settings->Base Reset**.
2. Enter the system PIN (default: 0000), and then press **Done**.
3. Select **Reset to factory**, and then press **OK**.

All individual settings of the base station will be reset to factory defaults. The power LED indicator and network status LED on the base station slowly flash in sequence during the resetting. LED indicators on the base station glow green after startup.

Important

Base station reset may take a few minutes. Do not power off until the base station starts up successfully.

Resetting the Handset

You can reset individual settings that you have configured on the handset. Resetting handset will not overwrite the settings of the directory, call history, voice mail and the handset registration. But other customized settings on the handset will be reset to factory after handset reset.

Procedure

1. Navigate to **OK->Settings->System Settings->Handset Reset**.
The phone prompts whether to reset the handset.
2. Press **Yes**.

Triggering the Auto Provisioning

Your system administrator may ask you to update your phone configurations. You can trigger the auto provisioning using the wizard.

Before You Begin

Get the user name and password to trigger provisioning.

Procedure


1. Navigate to **OK->Settings->System Settings->Auto Provision**.
2. Enter the system PIN (default: 0000) and then press **Done**.
3. Enter the user name, and then press **OK**.
4. Enter the password, and then press **OK**.
The phone prompts whether to update immediately.
5. Press **Yes**.

Appendix

Topics

- Appendix A- Menu Structure
- Appendix B - Input Modes and Characters

Appendix A- Menu Structure



Note

The menus in the gray box are not available when the handset is not registered to a base station.

Appendix B - Input Modes and Characters

	Abc (initials in capitals)	123	ABC	abc	ABГ	AAÄ	aaa	SŠš	sss	абв	АБВ
1	1	1	1	1	1	1	1	1	1	1	1
2 ABC	ABCabc2	2	ABC2	abc2	ABГ2	AAÄÄÄÄÄÄEBCČ	aaaääääääæbcč	AAÄÄBCČČČ2	aaaäbcččč2	АБВГ2	абвг2
3 DEF	DEFdef3	3	DEF3	def3	ΔEZ3	DEÈÈÈÈÈÈF3	deèèèèèèf3	DĚĚĚĚĚF3	dd'éeëëf3	ДЕЖЗ3	дежз3
4 GHI	GHIghi4	4	GHI4	ghi4	ΗΘΙ4	GĜHİİİİİİ4	gĝhiîîîîîî4	GHIİ4	ghiî4	ИЙКЛ4	ийкл4
5 JKL	JKLjkl5	5	JKL5	jkl5	ΚΛΜ5	JKL5	jkl5	JKLĹĹĹ5	jkĺĺĺ5	МНОП- 5	мноп5
6 MNO	MNOmno- 6	6	MNO- 6	mno6	NΞO6	MNÑOOÓÔÕÖ- Ø6	mnñooóôõö- ø6	MNŇŇOOÓÖ- Ŏ6	mnňñoóö- ő6	РСТУ6	рсту6
7 PQRS	PQRSpqrs- 7	7	PQRS- 7	pqrs7	ΠΡΣ7	PQRŠŠB7	pqrššb7	PQRŘŘSSŠ7	pqrřřssš7	ФХЦЧ7	фхцч7
8 TUV	TUVtuv8	8	TUV8	tuv8	ΤΥΦ8	TUÚÚÚÚÚÚV8	tuúúúúúúv8	TŤUÚÚÚÚÚV8	ttuúúúúúv8	ШЩЪЫ- 8	шщъы- 8
9 WXYZ	WXYZwxyz- z9	9	WXYZ- 9	Wxyz- 9	XΨΩΥ- 9	WŴXYŶZ9	wŵxyŷz9	WXYŶŶZŽŽŽ- 9	wxyŷŷžžž- 9	ЪЭЮЯ- 9	ъэюя9
0	space . , ? ! 0	0	0 . , ? ! space	0 . , ? ! space	space 0	space 0	space 0	space 0	space 0	0 Ğ Ğ Ğ Ğ	0 ğ ğ ğ ğ
*.	space = / \ ^ ; : , - + * # \$ % @ ? ! ; i () { } [] < > ¥ \$ £ ~ ¤	space _ ' " = / \ ^ ^ ; : , - + * # \$ % @ ? ! ; i () { } [] < > ¥ \$ £ ~ ¤	space _ ' " = / \ ^ ^ ; : , - + * # \$ % @ ? ! ; i () { } [] < > ¥ \$ £ ~ ¤	space _ ' " = / \ ^ ^ ; : , - + * # \$ % @ ? ! ; i () { } [] < > ¥ \$ £ ~ ¤	space _ ' " = / \ ^ ^ ; : , - + * # \$ % @ ? ! ; i () { } [] < > ¥ \$ £ ~ ¤	space _ ' " = / \ ^ ^ ; : , - + * # \$ % @ ? ! ; i () { } [] < > ¥ \$ £ ~ ¤	space _ ' " = / \ ^ ^ ; : , - + * # \$ % @ ? ! ; i () { } [] < > ¥ \$ £ ~ ¤	space _ ' " = / \ ^ ^ ; : , - + * # \$ % @ ? ! ; i () { } [] < > ¥ \$ £ ~ ¤	space _ ' " = / \ ^ ^ ; : , - + * # \$ % @ ? ! ; i () { } [] < > ¥ \$ £ ~ ¤	space _ ' " = / \ ^ ^ ; : , - + * # \$ % @ ? ! ; i () { } [] < > ¥ \$ £ ~ ¤	space _ ' " = / \ ^ ^ ; : , - + * # \$ % @ ? ! ; i () { } [] < > ¥ \$ £ ~ ¤